

## LITCHFIELD 42" ROUND DINING TABLE

Congratulations on your latest furniture purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time. Good luck – though we're confident you won't need it.

### BEFORE YOU BEGIN:

Check for damaged or missing parts. Email [customerservice1@LFProducts.com](mailto:customerservice1@LFProducts.com) to order missing supplies.

Use the carton as a working surface to prevent product damage during assembly.

This unit is heavy. Two people are required for assembly.

**DISCLAIMER:** *This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.*

The red TARGET Logo appears and fades from a white background.

The fully assembled tabletop appears on the screen.

The parts separate to give an exploded view and then reassemble before moving to the side of the screen as an outline sketch.

The parts for the assembly are labeled alphanumerically for convenience.

The round table top is labeled as A.

The leg side frame is labeled as B.

The four stretchers are all labeled as C.

The leg frame support is labeled as D.

The bottom leg is labeled as E.

The hardware parts included in the package show up onscreen and are marked as:

Washers as HW1X20

Lock washers as HW2X20

Small K D screws as HW4X22

Long K D screws as HW6X6

Hex wrench as HW21X1

The part B is taken and made to stand upright.

Two parts C are attached by the wedges into the holes on the side of B.

Two of them are attached on each side, facing upwards.

The part D is placed on the top, aligned with the indentation and holes on part B.

The structure is secured at the indentation with HW6X4. The screws are tightened with HW21.

The part D is secured with part C at the hole beside the wooden wedge with one HW4 on each side, tightened with HW21.

The entire unit is turned upside down.

The remaining parts C are attached by the wedges into the holes on the side of B.

The two of them are attached on each side, facing upwards.

Part E is attached the same way as part D, with parts B and Cs.

Part A is kept upside down and the entire assembled structure is taken upside down and aligned with the holes on part A.

All of the aligned holes are secured with HW1, HW2 and HW4, in that order. The screws are tightened with HW21 till perfectly secure.

The structure is made upright and is ready to use.

This unit has been designed to carry up to 400lbs. Exceeding this weight could result in excessive “sagging” of the top. Extreme overloading may cause failure of the top and possible injury.

This piece of furniture can be cleaned with a clean, lint-free cloth. Furniture spray can be used as and when needed.