

FULL ENCINO FULLY UPHOLSTERED PLATFORM BED - THRESHOLD™ DESIGNED WITH STUDIO MCGEE

Congratulations on your Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time.

Good luck -- thought we're confident you won't need it.

Before you begin

Check for damaged or missing parts.

If you have any questions, call Questions? Call 1-800-542-7553

Use the carton as working surface to prevent product damage during assembly.

Gather all tools prior to assembly.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The required hardware parts are:

The 1/4" bolts are labelled as (H1) x 10.

The 1/4" nuts are labelled as (H2) x 21.

The 3/4" x 5/16" bolts are labelled as (H3) x 4.

The 3/4" large hole washers are labelled as (H4) x 4.

The 1 x 1/4" bolts are labelled as (H5) x 15.

The 3/4" smaller hole washers are labelled as (H6) x 7.

The 1" x 5/16" bolts are labelled as (H7) x 6.

The 1 1/4" washers are labelled as (H8) x 6.

The small L wrench is labelled as (H9) x 1.

The large L wrench is labelled as (H10) x 1.

The wrench is labelled as (H11) x 1.

The 3/4" screws optional are labelled as (H12) x 8.

The L brackets optional are labelled as (H13) x 2.

NOTE:

You will need a flat head and phillips head screwdriver to assemble your bed frame.

The parts for assembly are identified alphanumerically for ease.

The four metal corners are labeled as A.

The two metal side rails are labelled as B.

The two metal end rails are labelled as C.

The four corner legs are labelled as D.

The center support rail is labelled as E.

The four center support legs are labelled as F.

The two upholstered side rails are labelled as G.

The upholstered foot rail is labelled as H.

The vertical support rail is labelled as I.

The two wooden slat rolls are labelled as J (Located in headboard box).

STEP 1:

Place (A) metal corners in a rectangular shape roughly the size of your mattress.

Lay (B) and (C) metal rails into (A) metal corners to create the shape of your bed frame.

Snap into place.

Secure (B, C) metal rails to (A) metal corners using (H1) bolts and (H2) nuts. Tighten using (H9) L wrench and (H11) wrench.

NOTE:

(H2) nuts should be on the inside of the frame.

Carefully attach (D) corner legs underneath (A) metal corners using (H3) bolts and (H4) washers. Tighten using (H10) L wrench.

STEP 2:

Align holes of (E) center support rail with holes on (B) metal side rails. Attach using (H1) bolts and (H2) nut. Tighten using (H9, H11) wrenches.

NOTE:

(E) center support rail attaches underneath (B) metal side rails.

Align hole of (I) vertical support rail with holes on (C) metal end rail. Attach using (H5) bolts, (H6) washers and (H2) nuts.

Attach (I) vertical support rail to (E) center support rails using (H5) bolts, (H6) washers and (H2) nuts. Tighten using (H9, H11) wrenches.

NOTE:

(I) vertical support rail attaches above (E) center support rail.

Attach (F) center support legs to (E,I) support rail using (H5) bolts and (H6) washer. Tighten using (H9) L wrench.

NOTE:

(F) center support legs can be adjusted in height by twisting the foot at the bottom of the leg.

Carefully place the (J) wooden slat rolls onto the bed frame. Attach using (H5) bolts and (H2) nuts. Tighten with (H9, H11) wrenches.

NOTE:

The black band that holds the slats together should face the floor.

STEP 3:

Loosely attach (G, H) upholstered rails to bed frame using (H7) bolts and (H8) washers.

NOTE:

If (G) upholstered side rails have an additional hole, make sure the hole faces upwards and away from the (H) upholstered foot rail.

Push (G) upholstered side rails toward (H) upholstered foot rail to eliminate any gaps. Tighten (G) upholstered side rails first, then (H) upholstered foot rail using flat head screwdriver.

OPTIONAL:

To reinforce stability of (G, H) upholstered rails, use a phillips screwdriver to attach (H13) L brackets using (H12) screws.

NOTE:

This requires screwing (H12) directly into the upholstered side rail.

ATTACHING YOUR HEADBOARD:

For instructions on how to attach your headboard to your bed frame, please consult the assembly instructions found in the box your headboard was shipped in.

LIMITED WARRANTY:

Skyline Furniture Inc. guarantees its upholstered furniture against defects in construction for a period of one (1) year. When a structural defect is brought to our attention, we will repair or replace it at our option at no charge to the customer (includes parts and labor, not transportation costs). Fabric wearability for upholstered furniture is not covered by the warranty. Vacuum for regular cleaning.

PLEASE DISPOSE OF PLASTIC BAG(S) AND CARTON(S) RESPONSIBLY.

Your assembly is complete. Your unit is now ready for use.
The red TARGET logo appears and fades from the screen.