

## 60" 4 SHELF LORING TRESTLE BOOKSHELF

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you will be on your way to transforming your room in no time.

Good luck -- though we are confident you won't need it.

Before you begin:

Check for damaged or missing parts. Call 1-800-440-0680 to order missing supplies. Use the carton as a working surface to prevent product damage during assembly. Gather all tools prior to assembly. The product requires two people to lift and assemble.

*DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.*

The required hardware parts are:

The 1/4" x 1-3/4" bolts are labeled as H1 x 16.

The 1/4" x 1/2" bolts are labeled as H2 x 16.

The M4.2 x 1/2" screw is labeled as H3 x 1.

The M4.2 x 1" screw is labeled as H4 x 1.

The strap is labeled as H5 x 1.

The wall anchor is labeled as H6 x 1.

The wrench is labeled as H7 x 1.

The parts for assembly are identified alphanumerically for ease.

The upper left frame is labeled as A.

The upper right frame is labeled as B.

The lower left frame is labeled as C.

The lower right frame is labeled as D.

The two back rails are labeled as E.

The shelf is labeled as F.

The shelf is labeled as G.

The shelf is labeled as H.

The shelf is labeled as I.

### HOW TO USE BARREL NUT WITH BOLT

The barrel nut is inserted and secured in the respective hole on the panel.

The panels are brought close to each other at right angles such that the bolt can be inserted into the barrel nut of the respective panels.

With the help of a screwdriver, the barrel nut is screwed in and tightened.

Make sure the bolts have been screwed down flush and not left partially inserted.

### STEP 1:

Attach the upper left frame (A) to the lower left frame (C) using four bolts (H2).

Attach the upper right frame (B) to the lower right frame (D) using four bolts (H2).

Fully tighten the bolts.

**STEP 2:**

Attach the shelves (F, G, H, I) to the left frame assembly using eight bolts (H1).

Attach the back rails (E) to the left frame assembly using two bolts (H2).

Do not fully tighten the bolts.

**NOTE:** Barrel nuts are pre-installed. Barrel nuts may need adjusting to properly align holes of the barrel nuts with bolts.

**STEP 3:**

Attach the right frame assembly to the assembled unit using eight bolts (H1) and four bolts (H2).

Apply firm pressure and fully tighten the screws and bolts.

**NOTE:** Barrel nuts are pre-installed. Barrel nuts may need adjusting to properly align holes of the barrel nuts with bolts.

**STEP 4:**

Attach strap (H5) to the assembled unit using one screw (H3).

Fully tighten the screw.

**STEP 5:**

Use the adjustable leveler at the legs to stabilize the unit.

**ANTI-TIP KIT INSTALLATION:**

Drill a 6.5mm diameter hole (1/4") in the wallboard.

Gently tap the wall anchor (H6) into the hole until it is flush.

Secure the strap (H5) already attached to the assembled unit to the wall anchor (H6) using M4.2 x 1" screw (H4).

**WARNING:**

Please make sure that all objects are removed before moving the assembled unit.

The unit must be team lifted, not dragged or pushed. Failure to do so could cause instability, product collapse and/or serious injury.

Exceeding the maximum weight limits could cause sagging, instability, product collapse and/or serious injury.

Your assembly is complete. Your unit is now ready for use.

The red TARGET logo appears and fades from the screen.