

## EAST BLUFF WOVEN DRAWER CONSOLE

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you will be on your way to transforming your room in no time.

Good luck -- though we are confident you won't need it.

Before you begin:

### IMPORTANT:

Complete all steps in this guide to ensure that drawers do not warp.

Check for damaged or missing parts. Please call 1-855-MYTGTHOME (855-698-4846) to order missing supplies. Place the items on a clean padded surface like a blanket for assembly. Gather all tools prior to assembly.

*DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.*

The required hardware parts are:

The wood dowels are labeled as H1 x 4.

The Allen wrench is labeled as H2 x 1.

The 1" bolts are labeled as H3 x 4.

The flat washers are labeled as H4 x 12.

The spring washers are labeled as H5 x 12.

The 1-1/4" screws are labeled as H6 x 8.

The screws are labeled as H7 x 6.

The handles are labeled as H8 x 3.

### ANTI-TIPPING HARDWARE:

The brackets are labeled as H9 x 2.

The plastic anchor is labeled as H10 x 1.

The screws are labeled as H11 x 2.

The screw is labeled as H12 x 1.

The zip tie is labeled as H13 x 1.

The parts for assembly are identified alphanumerically for ease.

The table top is labeled as A.

The two side frames are labeled as B.

The bottom panel is labeled as C.

### STEP 1:

Remove the drawers from the console table (A) before proceeding to the assembly steps.

Note: This is a very important step to avoid damage to parts during assembly.

#### STEP 2:

Attach the table top (A) to the side frame (B) and secure using 1-1/4" screws (H6) with spring washers (H5) and flat washers (H4). Tighten the screws (H6) using Allen wrench (H2).

Secure the bottom panel (C) to the side frame (B) using wood dowels (H1) and 1" bolts (H3) with spring washers (H5) and flat washers (H4). Tighten the bolts (H3) using Allen wrench (H2).

#### STEP 3:

Attach the other side frame (B) to the table top (A) and secure using 1-1/4" screws (H6) with spring washers (H5) and flat washers (H4). Tighten the screws (H6) using Allen wrench (H2).

Secure the other side frame (B) to the bottom panel (C) using wood dowels (H1) and 1" bolts (H3) with spring washers (H5) and flat washers (H4). Tighten the bolts (H3) using Allen wrench (H2).

#### STEP 4:

Slide the drawers back into the table top (A).

Use the adjustable lever at the legs to balance the unit if the floor is uneven.

Turn counterclockwise to increase height, clockwise to decrease height.

#### STEP 5:

Attach the bracket (H9) to the back of the product's top panel using screws (H11).

Using the other bracket (H9) as a template, mark a hole in the wall where this bracket (H9) will be installed.

Drill hole in the wall where marked. Ensure there are no hidden wires/ pipes in the wall before drilling.

Tap in the plastic anchor (H10) with a hammer and fix the bracket (H9) using screw (H12).

#### STEP 6:

Secure the brackets (H9) together with the zip tie (H13).

Your assembly is complete. Your unit is now ready for use.

The red TARGET logo appears and fades from the screen.