

TOURACO WOOD WRITING DESK WITH CARVED DRAWERS

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you will be on your way to transforming your room in no time.

Good luck -- though we are confident you won't need it.

Before you begin:

IMPORTANT:

Complete all steps in this guide to ensure that drawers do not warp.

Check for damaged or missing parts. Call 1-855-MYTGTHOME (1-855-698-4846) to order missing supplies. Use the carton as a working surface to prevent product damage during assembly. Gather all tools prior to assembly.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The required hardware parts are:

The long bolts are labeled as H1 x 8.

The short bolts are labeled as H2 x 8.

The spring washers are labeled as H3 x 8.

The large washers are labeled as H4 x 8.

The small washers are labeled as H5 x 8.

The Allen key is labeled as H6 x 1.

The 3/4" pan-head screws are labeled as H7 x 4.

The plastic restraints are labeled as H8 x 2.

The parts for assembly are identified alphanumerically for ease.

The top unit is labeled as A.

The four legs are labeled as B.

The left drawer is labeled as C.

The right drawer is labeled as D.

STEP 1:

Pull out the drawers (C, D) from the top unit (A).

STEP 2:

Attach the legs (B) to the top unit (A) using long bolts (H1), spring washers (H3) and small washers (H5).

Tighten the bolts (H1) using the Allen key (H6).

STEP 3:

Secure the legs (B) to the unit using short bolts (H2) and large washers (H4).
Tighten the bolts (H2) using the Allen key (H6).

STEP 4:

Attach the plastic restraints (H8) to the back of the unit using 3/4" pan-head screws (H7).
Attach the plastic restraints (H8) that have already been attached to the unit to the wall using wall screws and anchor (not provided).

STEP 5:

Slide the drawers into the unit.
Use the adjustable leveler at the legs to stabilize the unit.

Your assembly is complete. Your unit is now ready for use.
The red TARGET logo appears and fades from the screen.