

MINSMERE WRITING DESK WITH DRAWERS

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you will be on your way to transforming your room in no time.

Good luck -- though we are confident you won't need it.

Before you begin:

IMPORTANT:

Complete all steps in this guide to ensure that drawers do not warp.

Check for damaged or missing parts. Call 1-855-MYTGTHOME (1-855-698-4846) to order missing supplies. Use the carton as a working surface to prevent product damage during assembly. Gather all tools prior to assembly.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The required hardware parts are:

The long bolts are labeled as H1 x 2.

The short bolts are labeled as H2 x 4.

The 1 1/4" flat-head screws are labeled as H3 x 16.

The 3/4" flat-head screws are labeled as H4 x 8.

The cam lock bolts are labeled as H5 x 21.

The cam locks are labeled as H6 x 21.

The flat washers are labeled as H7 x 2.

The dowels are labeled as H8 x 6.

The Allen key is labeled as H9 x 1.

The 3/4" pan-head screws are labeled as H10 x 2.

The plastic restraints are labeled as H11 x 2.

The parts for assembly are identified alphanumerically for ease.

The top panel is labeled as A.

The left assembly is labeled as B.

The right assembly is labeled as B1.

The divider is labeled as C.

The front rail is labeled as D.

The bottom rail is labeled as E.

The back panel is labeled as F.

The left drawer front is labeled as G.

The right drawer front is labeled as G1.

The two drawers left are labeled as H.

The two drawers right are labeled as H1.

The two drawers back are labeled as H2.
The two drawers base is labeled as I.

HOW TO USE CAM LOCK SYSTEM

The cam bolt is inserted and secured in the respective hole on the panel.
The cam lock is inserted and secured in the hole present on the panel to be attached.
The panels are brought close to each other at right angles such that the cam bolt can be inserted into the cam lock of the respective panels.
With the help of a screwdriver, the cam lock is turned 180 degrees clockwise and tightened till the structure is perfectly secured.
Make sure the cam bolts have been screwed down flush and not left partially inserted.

STEP 1:

Insert the cam lock bolts (H5) into the pre-drilled holes in the top panel (A), left and right assemblies (B, B1), front rail (D), back panel (F), then tighten.
Screw-in cam lock bolts must be screwed down flush.

STEP 2:

Insert the cam locks (H6) into the holes in the top panel (A), divider (C) and back panel (F).
Make sure the arrow of the cam locks are pointing towards the end of the panel.

STEP 3:

Attach the divider (C) to the front rail (D) and back panel (F) using the cam lock system (H5, H6).

STEP 4:

Attach the top panel (A) to the unit using the cam lock system (H5, H6) and dowels (H8).

STEP 5:

Attach the left and right assemblies (B, B1) to the unit using the cam lock system (H5, H6) and dowels (H8).
Place the bottom rail (E) between the left and right assemblies (B, B1).

STEP 6:

Secure the left and right assemblies (B, B1) to the unit using long bolts (H1), short bolts (H2) and flat washers (H7), tighten using Allen key (H9).
Secure the bottom rail (E) to the left and right assemblies (B, B1) using short bolts (H2), tighten using Allen key (H9).

STEP 7:

Attach the plastic restraints (H11) to the back of the unit using 3/4" pan-head screws (H10).
Attach the plastic restraints (H11) that has already been attached to the unit to the wall using wall screw and anchor (not provided).
Use the adjustable leveler at the legs to stabilize the unit.

STEP 8:

Attach the drawer left and right (H, H1) to the drawer back (H2) using 1 1/4" flat-head screws (H3).

Make sure the heads of the screws are flush with the drawer sides.
Repeat for the remaining drawers.

STEP 9:

Slide the drawer base (I) into the groove.

STEP 10:

Attach the left and right drawers front (G, G1) to the left and right drawer units using 1 1/4" flat-head screws (H3).

Make sure the heads of the screws are flush with the drawer sides.

Make sure the drawer base (I) is inserted into the grooves in the drawers front (G, G1) and drawer back (H2).

STEP 11:

Slide the drawers into position.

WARNING:

Assembly process is not done until 3/4" flat-head screws are installed in a later step.
You are not allowed to use this unit unless all steps are done.

STEP 12:

If the drawer does not align, pull out the wrong drawer.

WARNING: Do not skip this step.

STEP 13:

Slightly untighten the screws.

Slide the drawer back into the unit.

Warning: Do not skip this step.

STEP 14:

Adjust the drawer's front panel left or right, up or down, until the drawer's gaps look proportional.
Pull out the drawer slowly.

WARNING: Do not skip this step.

STEP 15:

Tighten the loosen screws.

Make sure the front panel does not move and lock the drawer's front panel position with 3/4" flat-head screws (H4).

WARNING: Drawer assembly is not complete until 3/4" flat-head screws are installed in this step.

STEP 16:

If the drawer is already aligned, make sure the front panel does not move and lock the drawer's front panel position with 3/4" flat-head screws (H4).

WARNING: Drawer assembly is not complete until 3/4" flat-head screws are installed in this step.

STEP 17:

Slide the drawers into the unit.

Your assembly is complete. Your unit is now ready for use.

The red TARGET logo appears and fades from the screen.