

THOUSAND OAKS END TABLE

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you will be on your way to transforming your room in no time.

Good luck -- though we are confident you won't need it.

Before you begin:

IMPORTANT:

Complete all steps in this guide to ensure that drawers do not warp.

Check for damaged or missing parts. Call 1-855-MYTGTHOME (1-855-698-4846) to order missing supplies. Use the carton as a working surface to prevent product damage during assembly. Gather all tools prior to assembly.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The required hardware parts are:

The bolts are labeled as H1 x 8.

The 1 1/4" flat-head screws are labeled as H2 x 16.

The 3/4" flat-head screws are labeled as H3 x 8.

The 5/8" flat-head screws are labeled as H4 x 6.

The 1/2" flat-head screws are labeled as H5 x 4.

The cam lock bolts are labeled as H6 x 12.

The cam locks are labeled as H7 x 12.

The handles are labeled as H8 x 2.

The wooden dowels are labeled as H9 x 8.

The wedges are labeled as H10 x 6.

The spring washers are labeled as H11 x 8.

The flat washers are labeled as H12 x 8.

The Allen wrench is labeled as H13 x 1.

The parts for assembly are identified alphanumerically for ease.

The top panel is labeled as A.

The left panel is labeled as B.

The right panel is labeled as C.

The bottom assembly is labeled as D.

The back panel is labeled as E.

The four legs are labeled as F.

The two drawer front are labeled as G.

The two drawer left are labeled as H.

The two drawer right are labeled as I.

The two drawer back are labeled as J.

The two drawer base are labeled as K.

HOW TO USE CAM LOCK SYSTEM

The cam bolt is inserted and secured in the respective hole on the panel.

The cam lock is inserted and secured in the hole present on the panel to be attached.

The panels are brought close to each other at right angles such that the cam bolt can be

inserted into the cam lock of the respective panels. With the help of a screwdriver, the cam lock is turned 180 degrees clockwise and tightened till the structure is perfectly secured. Make sure the cam bolts have been screwed down flush and not left partially inserted.

STEP 1:

Insert the cam lock bolts (H6) into the pre-bored holes of the top panel (A) and the bottom assembly (D).

Screw-in cam lock bolts must be screwed down flush.

STEP 2:

Insert the cam locks (H7) into the holes of the left and right panels (B, C).

Make sure the arrows of the cam locks are pointing towards the end of the panel.

STEP 3:

Attach the left and right panels (B&C) to the bottom assembly (D) using cam locks (H7) and wooden dowels (H9).

STEP 4:

Slide the back panel (E) into the groove of the unit.

NOTE:

Put the surface with component code sticker facing inside.

STEP 5:

Attach the top panel (A) to the unit using cam locks (H7) and wooden dowels (H9).

STEP 6:

Attach the legs to the unit using bolts (H1), spring washers (H11) and flat washers (H12).

Tighten the bolts (H1) using Allen key (H13).

STEP 7:

Attach the wedges (H10) to the unit using 5/8" flat-head screws (H4).

STEP 8:

Attach the drawers left and right (H, I) to the drawer back (J) using 1 1/4" flat-head screws (H2).

Make sure the heads of the screws (H2) are flush with the drawer sides.

STEP 9:

Slide the drawer base (K) into the groove.

STEP 10:

Attach the drawer front (G) to the drawers left and right (H, I) using 1 1/4" flat-head screws (H2).

Make sure the heads of the screws (H2) are flush with the drawer sides.

Make sure the drawer base (K) is inserted into the grooves in the drawers front and back (G, J).

STEP 11:

Attach the handles (H8) to the drawer using 1/2" flat-head screws.

STEP 12:

Slide the drawers into the unit.

Use the adjuster attached to the legs to adjust the unit.

STEP 14:

If the drawer does not align, pull out the wrong drawer.

STEP 15:

Slightly untighten the screws (H2).

Insert the drawer back into the main body.

STEP 16:

Adjust the drawer front panel (G) left or right, up or down, until the drawer's gaps look proportional. Pull out the drawer slowly.

STEP 17:

Tighten the loosen screws (H2).

Make sure the front panel (G) does not move and lock the front panel position with 3/4" flat-head screws (H3).

STEP 18:

If the drawer is already aligned, make sure the front panel (G) does not move and lock the front panel position with 3/4" flat-head screws (H3).

STEP 19:

Slide the drawers into the unit.

Your assembly is complete. Your unit is now ready for use.

The red TARGET logo appears and fades from the screen.