METAL/GLASS ETAGERE

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time.

Good luck -- though we're con dent you won't need it.

Before you begin Check for damaged or missing parts. Call 1-855-698-4846. Use the carton as a working surface to prevent product damage during assembly. Gather all tools prior to assembly. Unpack all hardware bags and components to ensure you have all parts. Read instructions, cover to cover. Do not assemble on flooring or carpet. Assemble on a clean non-marring surface (packing foam). Care & Maintenance Do not put hot items directly on furniture surface.

Do not clean furniture with harsh cleansers or polish.

Do not place furniture in direct sunlight.

Do not place furniture near heating or cooling vents.

Do not write on furniture without a padded barrier to protect the surface.

Do not place furniture outside. For indoor use only.

Not for commercial use, for residential use only.

Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Stains may be removed with mild soap solution and damp cloth.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The parts for assembly are identified alphanumerically for ease. The shelf frames are labeled as (A) x 3. The top tubes are labeled as (B) x 4. The bottom tubes are labeled as (B1) x 4. The connecting frame is labeled as (C) x 1. The glass are labeled as (D) x 3. The connecting strip is labeled as (E) x 1. The connecting tube (big) is labeled as (F) x 1. The connecting tube (small) is labeled as (G) x 1.

For ease of identification, all hardware is organized into separate hardware packs.

The allen bolts M6x20 are labeled as (H) x 18.

The allen bolts M6x8 are labeled as (H1) x 6.

The allen key is labeled as (I) x 1.

STEP 1:

Place the Shelf frame (A) on floor. Than attach the Top tube (B) with Shelf Frame (A) and secure with the help of two Allen bolt (H) and Allen key (I).

Repeat this process for the two other Shelves (A). Make sure bumper dots should be up side.

STEP 2:

Place the assembled Top tubes (B) on floor. Then attach the Connecting frame (C) and Top tubes (B) with the help of six Allen bolt (H) each and Allen key (I).

STEP 3:

Attach Tube (B1) with Connecting tube (G). Then secure with the help of two Allen bolt (H) and Allen key (I).

Follow this step for both frame assembly.

STEP 4:

Place the Top assembly on floor and Insert both Side frame (Already assembled in STEP 3) into Top assembly with little force and secure only back pipes with the help of two Allen bolt (H1) and Allen Key (I).

STEP 5:

Attach the Connecting strip (E) to the front pipes. Then secure with the help of four Allen bolts (H1) and Allen key (I).

STEP 6:

Attach the Connecting tube (F). Then secure with the help of two Allen bolts (H) and Allen key (I).

All Allen bolts should be tightened 100%.

STEP 7:

Place the Rack on floor vertically and put the glass shelves very carefully in to the frames (A) on Bumper dots.

ANTI-TOPPLE KIT INSTRUCTION

You must secure your furniture to the wall in accordance with the following instructions to prevent injury/property damage from unexpected tipping furniture.

The parts for assembly are identified alphanumerically for ease: The anchors are labeled as A \times 4. The screws are labeled as B \times 4. The wall brackets are labeled as C \times 2. The cable ties are labeled as D \times 2.

To secure wall bracket (C) to wall:

Position your furniture in the washroom near wall in specific area. Attach the wall bracket with wall vertically and marks the holes with the help of pencil. Make drill holes on marking points. (Seek professional advise if unsure of wall construction). Insert the Anchor into the drill holes with help of soft hammer. Secure the wall bracket on wall with provided Screws (B).

To secure furniture to wall bracket (C):

Position your furniture near pre-fixed wall bracket.

Feed small end of Cable tie (D) through the side of fixed Wall bracket (C).

Repeat the same step to secure other Bracket (C), then reposition furniture in place.

Loop cable tie through pre-fixed Wall bracket and connect the Cable tie (D). The cable tie should have both Wall Bracket (C) and the product connected. Finish position of furniture if required, then pull tight the Cable Tie (D). NOTE

Weight capacity 20 lbs (9 kg) each shelf.

NEEDED TOOLS (NOT INCLUDED)

You will need a drill, a drill bit 6.0mm, a Phillips head screwdriver, and a measuring tape.

TO SECURE WALL BRACKET TO WALL:

Install tip-over restraint provided.

Unless specifically designed to accommodate, do not hang other heavy objects. Never allow children to climb or hang on this product and fitting.

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

To help prevent tip-over:

Install tip-over restraint provided.

Place heaviest items on the lowest surfaces as far back from the front edge as possible. Do not set TVs or other heavy objects on top of this product, unless the product is specifically designed to accommodate them.

Never allow children to climb or hang on drawers, doors, or shelves.

Use of tip-over restraints may only reduce, but not eliminate the risk of the tip over.

Your assembly is complete. Your unit is now ready for use. The red TARGET logo appears and fades from the screen.