

## 6'X6' ARBOR

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time. Good luck- though we're confident you won't need it.

Before you begin

Check for damaged or missing parts.

Use the carton as a working surface to prevent product damage during assembly.

Gather all tools prior to assembly.

*DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.*

The assembly and hardware parts are labeled below

The roof is labelled as A.

The two sides are labelled as B.

The two shelves are labelled as C.

The eight shelf brackets are labelled as D.

The four legs are labelled as E.

The M6\*20 bolts are labelled as F x 24.

The M6\*35 bolts are labelled as G x 6.

The allen key is labeled as H.

The allen screws are labelled as I x 8.

### STEP 1:

Attach the roof to the sides, using F. Tighten the screws.

### STEP 2:

Secure the previous formation with D, on both upper corners, joining A and B. Use F and tighten the screws.

### STEP 3:

Attach the side shelves using D and screw in the bolts.

### STEP 4:

Position the leg supports (E) and screw them in using F.

### STEP 3:

Tighten all the bolts with supplied allen key.

Your assembly is complete. Your unit is now ready for use.

The red TARGET logo appears and fades from the screen.