## 72" 5 SHELF LORING LADDER BOOKSHELF

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you will be on your way to transforming your room in no time.

Good luck -- though we are confident you won't need it.

# Before you begin:

Check for damaged or missing parts. Call 1-800-440-0680 to order missing supplies. Use the carton as a working surface to prevent product damage during assembly. Gather all tools prior to assembly. The product requires two people to lift and assemble.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The required hardware parts are:

The 1/4" x 2" bolts are labeled as H1 x 16.

The 1/4" x 1-3/8" bolts are labeled as H2 x 4.

The 1/4" x 1/2" bolts are labeled as H3 x 8.

The M4.2 x 1-3/8" screws are labeled as H4 x 6.

The M4.2 x 1" screw is labeled as H5 x 1.

The M4.2 x 1/2" screw is labeled as H6 x 1.

The strap is labeled as H7 x 1.

The wall anchor is labeled as H8 x 1.

The wrench is labeled as H9 x 1.

The parts for assembly are identified alphanumerically for ease.

The upper left frame is labeled as A.

The upper right frame is labeled as B.

The lower left frame is labeled as C.

The lower right frame is labeled as D.

The upper back rail is labeled as E.

The lower back rail is labeled as F.

The three shelves are labeled as G.

The shelf is labeled as H.

The shelf is labeled as I.

# HOW TO USE BARREL NUT WITH BOLT

The barrel nut is inserted and secured in the respective hole on the panel.

The panels are brought close to each other at right angles such that the bolt can be inserted into the barrel nut of the respective panels.

With the help of a screwdriver, the barrel nut is screwed in and tightened.

Make sure the bolts have been screwed down flush and not left partially inserted.

## STEP 1:

Attach the lower back rail (F) to the shelf (I) using three M4.2 x 1-3/8" screws (H4). Attach the upper back rail (E) to the shelf (H) using three M4.2 x 1-3/8" screws (H4). Fully tighten the screws.

## STEP 2:

Attach the upper left frame (A) to the lower left frame (C) using four 1/4" x 1/2" bolts (H3). Attach the upper right frame (B) to the lower right frame (D) using four 1/4" x 1/2" bolts (H3). Fully tighten the bolts using the wrench (H9).

#### STEP 3:

Attach the shelves (G) to the assembled left frame using two 1/4" x 2" bolts (H1) for each shelf. Attach the shelves (H, I) to the assembled left frame using one 1/4" x 2" bolts (H1) and one 1/4" x 1-3/8" bolts (H2) for each shelf.

Do not fully tighten the bolts.

NOTE: Barrel nuts are pre-installed. Barrel nuts may need adjusting to properly align holes of barrel nuts with bolts.

## STEP 4:

Attach the assembled right frame to the assembly using eight 1/4" x 2" bolts (H1) and two 1/4" x 1-3/8" bolts (H2).

Apply firm pressure to align and fully tighten the bolts using wrench (H9).

NOTE: Barrel nuts are pre-installed. Barrel nuts may need adjusting to properly align holes of barrel nuts with bolts.

#### STEP 5:

Attach the strap (H7) to the unit using M4.2 x 1/2" screw (H6). Fully tighten the bolt.

## STEP 6:

Use the adjustable leveler at the legs to stabilize the unit.

## ANTI-TIP KIT INSTALLATION:

Drill a 6.5mm diameter hole (1/4") in the wallboard.

Gently tap the wall anchor (H8) into the hole unit it is flush.

Secure the strap (H7) already attached to the assembled unit to the wall anchor (H8) using M4.2 x 1" screw (H5).

## WARNING:

Please make sure that all objects are removed before moving the assembled unit.

The unit must be team lifted, not dragged or pushed. Failure to do so could cause instability, product collapse and/or serious injury.

Exceeding the maximum weight limits could cause sagging, instability, product collapse and/or serious injury.

Your assembly is complete. Your unit is now ready for use. The red TARGET logo appears and fades from the screen.