HARWELL MODERN ARM BARREL CHAIR WITH METAL LEGS SHERPA

Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time.

Good luck - though we're confident you won't need it.

Before you begin

Check for damaged or missing parts. Call 1-855-MYTGTHOME (855-698-4846) to order missing supplies. Please reference DPCI# 249-08-0115, 249-08-2689 or 249-08-1870. Use the carton as a working surface to prevent product damage during assembly. Gather all tools prior to assembly.

Do not tighten bolts completely until assembly is complete.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The hardware is labeled alphabetically below The M6x30mm bolts are labeled as Bolts x 12. The spring washers are labeled as spring washers x 12. The flat washers are labeled as Flat washer x 12. The allen key is labeled as Allen Key x 1.

The assembly parts are labeled alphabetically for ease The seat is labeled as A x 1. The left legs are labeled as B x 2. The right legs are labeled as C x 2.

STEP 1:

Attach front legs to seat with 30mm bolts, spring washers and flat washers using allen key. Tighten all bolts using allen key.

IMPORTANT: For ease of assembly, two adults are recommended. Please use hand tools to assemble this product. Do not use power tools

STEP 2:

Attach back legs to seat with 30mm bolts, spring washers and flat washers using allen key. Tighten all bolts using allen key.

STEP 3:

If your chair is not level, put it on a hard surface, then adjust the levelers

STEP 4:

WARNING Maximum weight: 275 lbs. Your assembly is complete. Your unit is now ready for use.

The red TARGET logo appears and fades from the screen.