

COPLEY COUNTER STOOL

Congratulations on your Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time.

Good luck -- thought we're confident you won't need it.

Before you begin

Check for damaged or missing parts. Call 1-800-440-0680 to order missing supplies.

Use the carton as working surface to prevent product damage during assembly.

Gather all tools prior to assembly.

DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.

The required hardware parts are:

The M6 bolts are labeled as (H1) x 4.

The M6 bolts are labeled as (H2) x 2.

The M6 bolts are labeled as (H3) x 2.

The M6 bolts are labeled as (H4) x 4.

The M4 allen key is labeled as (H5) x 1.

The M5 allen key is labeled as (H6) x 1.

The parts for assembly are identified alphanumerically for ease.

The seat is labeled as A.

The two legs are labeled as B.

The round plate is labeled as C.

The ring stretcher is labeled as D.

STEP 1:

Place the two legs (B) on a flat surface and attach the round plate (C) with four M6 bolts (H1).

NOTE:

Do NOT fully tighten bolts at this step until STEP 3.

STEP 2:

Align the holes of the ring stretcher (D) with the two legs (B) and attach with four M6 bolts (H4).

STEP 3:

Align the marking on the round plate (C) with the bottom of seat (A) to ensure that the legs face the correct direction.

Attach the two M6 bolts (H3) to the front of the round plate (C).

Attach the two M6 bolts (H2) to the rear of the round plate (C).

NOTE:

Please insure that all bolts are tightened

WEIGHT LIMITS:
250lbs / 113kgs.

Your assembly is complete. Your unit is now ready for use.
The red TARGET logo appears and fades from the screen.