PL4441 FLOOR LAMP

Congratulations! You've purchased a fine lighting item from Target.

We have designed our floor lamp with you, the Target guest in mind. Our clear, easy to follow, step by step instructions will guide you through the project from start to finish. We feel confident that this will be a fun and rewarding project. The final product will be a quality lamp that will go together smoothly and give years of enjoyment.

Carefully unpack and identify each part to make sure you have everything ready for installation. Lay out each part on a clean flat area such as a table or carpet. Check to make sure you have the following:

The butterfly nut is labeled as A.

The flat washer is labeled as B.

The base is labeled as C.

The square tube is labeled as D.

The tube is labeled as E.

The round tube is labeled as F.

The square tube is labeled as G.

The square tube is labeled as H.

The square tube is labeled as I.

The square tube is labeled as J.

The Max 40 watt dimmable type B bulbs are labeled as K (Not included).

The three glass shades are labeled as L.

STEP 1:

Fasten round tube (H) onto the threaded tube on tube (J), before moving to the next step, please make sure that tube (H) has been fully tightened (cannot be turned clockwise).

STEP 2:

Slide rectangle tube (I) over round tube (H), and then insert the square tube (I into the square tube J), before moving to the next step, please make sure there is no gap between the two square tubes (J and I).

STEP 3:

Fasten round tube (F) onto square tube (H), before moving to the next step, please make sure the tube (F) has been fully tightened (cannot be turned clockwise).

STEP 4:

Slide rectangle tube (G) over round tube (F), and then insert the square tube (G) into the square tube (H), before moving to the next step, please make sure there is no gap between the two square tubes (G and H).

STEP 5:

Fasten round tube (E) onto round tube (F), before moving to the next step, please make sure the tube (E) has been fully tightened (cannot be turned clockwise).

STEP 6:

Slide rectangle tube (D) over round tube (E), and then insert the square tube (D) into the square tube (G), before moving to the next step, please make sure there is no gap between the two square tubes (D and G).

STEP 7:

One person holds the square tubes (I) and (D), and the other holds the base. Put the tube (E) through the base (C), make sure the four corners of the tube (D) are aligned with the four corners of the part M (Pre-assembled on base C), also please make sure the socket is perpendicular to the cord grommet.

Before locking the base, please make sure there is no gap between the square tubes J/I/G/D, also there is no gap between the square tube (D) and the base (C). Then screw with flat washer (B) and butterfly nut (A).

STEP 8:

Screw Max 40 watt dimmable type B bulbs (K) (not included) onto each socket, then carefully screw each glass shade (L), (total 3pcs), and tighten. Use the inline dimmable step switch to turn light on/off.

If need to replace the bulbs, loosen the glass shade.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other). As a safety Feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Your assembly is complete. Your unit is now ready for use. The red TARGET logo appears and fades from the screen