

## SOUTHPORT 2PK PATIO CLUB CHAIRS WITH METAL LEGS

Congratulations on your Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time.

Good luck -- thought we're confident you won't need it.

### IMPORTANT WARNING:

Unpack the box on a clean, soft, level surface and make sure all parts have been included. To replace missing or damaged parts please call 855-MYTGTHOME (855-698-4846) during 7am - 7pm CST M-F, and 8am - 5pm CST Saturday.

### ATTENTION:

This Chair is not intended for use during any kind of inclement weather and the manufacturer is not, and cannot be held responsible for any damages caused as a result of such weather. Weather-related damage, or damage as a result of the Chair not being stored properly when not in use, is not the responsibility of the manufacturer.

During extended periods of non-usage, off season, or in inclement weather (wind, rain, snow, hail, sleet), freezing conditions and extreme heat, the Chair needs to be stored in a dry, sheltered place to prolong the life and to avoid damage to the Chair.

### WARRANTY

This Chair comes with a one year limited warranty against original manufacture defects. If you experience trouble with your chair, please call the customer service number below.

Target Corporation Toll Free at: 855-MYTGTHOME (855-698-4846) during 7am - 7pm CST M-F, and 8am - 5pm CST Saturday. Code: Yotrio 2022

Before you begin:

Check for damage or missing parts. Call 855-MYTGTHOME (855-698-4846) to order missing supplies.

Use the carton as a working surface to prevent product damage during assembly.

Gather all tools prior to assembly.

*DISCLAIMER: This video incorporates the instructions provided by the manufacturer with this product. Target will not be liable for any damage or injury based on your reliance on the content provided.*

The required hardware parts are:

The M6\*35mm screws with washers are labeled as (Part C) x 8.

The allen wrench is labeled as (Part D) x 1.

### ATTENTION:

The hardware kit is for 2 chairs.

The parts for assembly are identified alphanumerically for ease.

The two chair baskets are labeled as A.

The two chair bases are labeled as B.

**STEP 1:**

**ATTENTION:** To avoid damage to your new patio furniture, please use either the carton or another soft surface such as carpet as a working surface to prevent product damage during assembly.

Attach the chair base (B) to the chair bracket (A) by lining up screw holes on the chair base (B) with corresponding screw holes on the chair bracket (A).  
Secure with M6\*35mm screw and washer (C) using allen wrench (D).

**STEP 2:**

Tighten all the screws.  
Turn the chair to upright position on a flat level surface.  
Put the cushion on the chair.  
Repeat these steps for another chair

For longer life, cover and store when not in use.

**Frame Care:**

Wipe clean with damp cloth. Use only mild soap and detergents.

Your assembly is complete. Your unit is now ready for use.  
The red TARGET logo appears and fades from the screen.